



INSTALLATION INSTRUCTION



Bubble Level x1



Max: 400x400mm/16x16"
Min: 75x75mm/3x3"



Safety Caution

Please read this instruction carefully before installation.
If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, please contact us.


- This product is designed for use in wood stud or solid concrete wall.
- **DO NOT install into drywall alone.**
- The wall must be capable of supporting five times the weight of the TV and mount combined.
- Incorrect installation may result in product damage or body injury.

⚠ WARNING: This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; please contact our customer service team. Never use damaged parts!

Must Check Before Getting Started




Drywall with wood studs





Solid concrete wall

⚠ CAUTION: DO NOT install into drywall alone.


Extra Tools You Need (Not Supplied)









Supplied Parts and Hardware



Lag Bolt ST6x60mm





TV Screws / Spacers / Washers

Philips Screws M4 x 12mm M4 x 30mm	Philips Screws M6 x 15mm M6 x 30mm	Philips Screws M8 x 25mm M8 x 45mm	Spacers L10mm	Washers Ø6mm M4-5-6	Spacers L5mm
 x4	 x4	 x4	 x8	 x4	 x8
MA	MB	MC	MD	ME	MF

NOTE: Not all parts and hardware included will be used.

Attach TV Brackets

1-1 Select TV Screws




Too Short




Too Long



Not Vertical





Correct




Correct

1-2 Need Spacer?


I Yes, choose the appropriate screws, washers, and spacers for your TV.




For more spacing between bracket and TV



For raised back TV




For Counterbore of TV





To avoid the blocked input

II No, just choose the screws, washers.




1-3 Attach the TV Brackets




Attach Wall Plate to Wall

OPTION A: Wood Stud Installation


A-1



A-2




A-3



Be sure to drill into the center of the stud.

A-4




Install wall plate using lag bolts and washer with Socket Wrench, NO Electrodrill.

CAUTION: To avoid potential personal injury or property damage:
All 4 lag bolts **I** **MUST BE** firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.


Attach Wall Plate to Wall

OPTION B: Solid Concrete Wall Installation


B-1




B-2



B-3



B-4




Install wall plate using lag bolts, washer and anchor with Socket Wrench, NO Electrodrill.

CAUTION: To avoid potential personal injury or property damage:
All 4 lag bolts **I** **MUST BE** firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.

Hang and Secure TV to Wall Plate


3-1 Wall Plate Installation Integrity Test

Before hanging TV, please conduct "wall plate installation integrity test" first.



3-2 Hang and Secure TV to Wall Plate


Hang TV with brackets onto the Plate.




Adjustments

Tilting adjustment


Adjust TV to desired angle then fasten tilting bolts with hands.



Option: To keep TV in vertical position, please use two M4 screws (MA) to insert the holes on two brackets respectively (as shown in below image).



Remove TV



Product Dimensions

